LC original SPOTS TRACING PATTERN PASSING DRP01

Spots Pattern A

Puffed Diamond Spot < 16mm $> \times$ 1 Round Head Spot < 3mm $> \times$ 6 Round Head Spot < 4.5mm $> \times$ 6 Diamond Spot < 9.5mm $> \times$ 2

Pattern B

Round Head Spot < 3mm > × 14 Round Head Spot < 4.5mm > × 4 Round Head Spot < 6mm > × 1 Pyramid Spot < 4.8mm > × 2 Diamond Spot < 9.5mm > × 2


Tools

- Spot Setting Tool No.0 (For punching holes to attach Puffed Diamond Spot < 16mm >)
 Spot Setting Tool No.1 (For punching holes to attach Round Head Spot < 3mm >)
- •Spot Setting Tool No.2 (For punching holes to attach Round Head Spot <4.5mm>)
- Spot Setting Tool No.2.5 (For punching holes to attach Pyramid Spot < 4.8mm>)
- •Spot Setting Tool No.3 (For punching holes to attach Round Head Spot <6mm>)
- Spot Setting Tool No.4 (For punching holes to attach Diamond Spot < 9.5 mm >)
- •Plier (For bending spots prongs)
- Mallet (For hammering hole punch)
- Rubber Board (Underlay for hole punch)
- •Round Hole Punch #8 (2.5mm)

(For punching a hole for a snap fastener.In case you want to turn it into a lady-sized item.)

How to use

Enable tracing locations for setting spots (where to punch holes)in sequence of the below design. You can make arrangement for setting studs by tracing the patterns on a wallet, a belt, and so on. Use them as patterns by pasting on thick paper such as card board.



Leather Bracelet Kit 15

Pattern A










0

Pattern B










0

Turn it into a lady-sized item.

You can turn it into a lady-sized item by cutting it short and remaking holes as shown below. (Please cut about 2 cm as a rough standard.)

Pattern A












For punching for snap fasteners, please use round hole punch #8 (about 2.5 mm).

Pattern B














※All rights reserved.

